

ALARM CHRONOGRAPH

SEIKO SERIES SNA (7T62)

FEATURES

- ◆ Hour, minute and small second hands.
- ◆ Alarm can be set on a 12-hour basis with two small hands.
- ◆ Date calendar.
- ◆ Chronograph can measure up to 60 minutes in 1/5 seconds. After 60 minutes, it will start counting again from "0" repeatedly up to 12 hours.
- ◆ Alarm hands can indicate the time in a different time zone.

HOW TO SET TIME

1. Pull crown out to the second click position and turn to set hour and minute hands to current time.
2. Push back crown into normal position.

HOW TO SET CALENDAR

1. Date Setting
 - Pull crown out to the first click position and turn clockwise to set calendar to the present date.
 - Push crown back into normal position.

HOW TO SET ALARM TIME

1. Pull the crown out to the second click position.
2. Press button "B" to set the alarm hour and minute hands to current time.
3. Push the crown back to normal position.
4. Pull the crown to the first click position.
5. Press button "B" to set the alarm hour and minute hands to desired alarm time.
6. Push the crown back to normal position.

Note:

Alarm setting on a 12-hour basis only. Alarm will ring at the designated time for 20 seconds; one time alarm only. The alarm needs to be reset in order to re-engage the alarm function.

HOW TO USE CHRONOGRAPH

1. Set crown at normal position.
2. Press button "A" to Start/Stop/Restart.
3. Press button "B" to Split/Split release/Reset.

HOW TO USE ALARM DIAL AS DUAL TIME DISPLAY

1. Pull the crown out to the second click position.
2. Press the button "B" to set the hour and minute hands to time of a different time zone.
3. Push the crown back to normal position.

HOW TO USE ADJUSTING HAND POSITION

If the stopwatch hands are not in the "0" (12 o'clock) position, follow the procedure below to set them to the 12 o'clock position.

1. Pull the crown to second position.
2. Press button "A" for two (2) seconds.
3. Press button "B" to adjust the minute hand to "0" position.
4. Press button "A" for two (2) seconds then press button "B" to adjust second hand to "0" position.
5. Press crown into normal.

